

July 2008

**A**

AC Contactors — *see* Contactors

AC Lighting Contactors

Electrically Held . . . . . **E-2 – E-7**

Magnetically Latched . . . . . **E-17 – E-19**

Mechanically Held . . . . . **E-8 – E-16**

AC Relays — *see* Relays

AC Starters — *see* Starters

Accessories

Advantage Contactors & Starters . . . . . **A-119 – A-123,**  
**A-132 – A-134**

A200 Contactors & Starters . . . . . **A-91 – A-93**

Definite Purpose

Contactors & Starters . . . . . **C-7 – C-9, C-13, C-33,**  
**C-36, C-41, C-43, C-45, C-47**

Freedom Contactors & Starters

IEC . . . . . **B-208 – B-213**

NEMA . . . . . **A-39 – A-47**

*IT* Contactors & Starters

IEC . . . . . **B-194 – B-197**

NEMA . . . . . **A-13 – A-16**

Manual Motor Protector

*XT* IEC . . . . . **B-118 – B-129**

Miniature IEC Controls . . . . . **B-21 – B-23**

Soft Start Reduced Voltage

Controls . . . . . **G-19, G-31, G-32, G-46,**  
**G-47**

Vacuum Contactors & Starters . . . . . **D-4**

*XT* Contactors & Starters

IEC . . . . . **B-47 – B-56**

Adapter Plates for Starters . . . . . **A-16, A-46, A-47,**  
**A-121, B-95, B-197, B-221**

Advantage Motor Control . . . . . **A-108 – A-134**

Advantage Control Modules . . . . . **A-122, A-123**

Central Monitoring Unit . . . . . **A-132, A-133**

Contactors . . . . . **A-109**

Multispeed . . . . . **A-112, A-113**

Starters . . . . . **A-110 – A-113**

Auxiliary Contact Kits

Advantage . . . . . **A-119**

A200 . . . . . **A-91, A-93**

Definite Purpose . . . . . **C-7, C-8, C-36, C-41,**  
**C-43, C-45, C-47**

Freedom

IEC . . . . . **B-218**

NEMA . . . . . **A-43, A-44**

*IT*

IEC . . . . . **B-196**

NEMA . . . . . **A-15**

Lighting . . . . . **E-3**

Miniature IEC . . . . . **B-5, B-21**

MMPs . . . . . **B-118, B-119**

Vacuum . . . . . **D-4**

*XT* IEC . . . . . **B-6, B-47 – B-51, B-118, B-119**

**B**

Bimetallic Overload Relays

A200 . . . . . **A-99 – A-107**

Freedom

IEC . . . . . **B-214, B-215**

NEMA . . . . . **A-60 – A-65**

Miniature IEC . . . . . **B-20**

*XT* IEC . . . . . **B-93 – B-101**

Blocks, Fuse . . . . . **A-39, A-92, B-221, C-9**

Brakes, Magnetic Shoe . . . . . **A-141 – A-144**

**C**

Central Monitoring Unit (Advantage) . . . . . **A-132, A-133**

Citation Renewal Parts . . . . . **A-135 – A-137**

Coil Controllers

Modular *IT* Components . . . . . **A-14, B-195**

Coils

DC for Contactors and Starters . . . . . **A-17, A-45,**  
**A-46, A-93, A-95, B-57,**  
**B-220, C-31, C-38, C-43,**  
**C-45, C-47, D-5**

Magnet, Renewal Parts . . . . . **B-225 – B-229, C-34,**  
**C-38, C-39, D-5**

Overload Relay Heater . . . . . **A-62 – A-65, A-106,**  
**A-107, D-4**

Combination Motor Controllers

*XT* IEC . . . . . **B-145 – B-161**

Communication Devices . . . . . **A-119**  
**A-132 – A-134**

Contact Blocks

Modular *IT* Components . . . . . **B-195**

Contact Kits

Auxiliary — *see* Auxiliary Contact Kits

Renewal Parts . . . . . **A-17, A-48 – A-50, A-95,**  
**A-96, A-121, A-135 – A-138, B-57,**  
**B-198, B-225 – B-229, C-29, C-34,**  
**C-39, C-41, C-43, C-45, C-48**

Contactors

AC Lighting . . . . . **E-1 – E-19**

Advantage . . . . . **A-109**

A200 . . . . . **A-74 – A-76**

DC . . . . . **C-36 – C-48**

Definite Purpose . . . . . **C-1 – C-10**

For Three-Phase Capacitors (*XT*) . . . . . **B-46**



- Contactors, continued  
   Freedom  
     IEC ..... **B-207 – B-210**  
     NEMA ..... **A-27 – A-29**  
   **IT**  
     IEC ..... **B-180 – B-182**  
     NEMA ..... **A-4 – A-6**  
   Lighting ..... **E-1 – E-19**  
     Electrically Held ..... **E-2 – E-7**  
     Magnetically Latched ..... **E-17 – E-19**  
     Mechanically Held ..... **E-8 – E-16**  
   Miniature IEC ..... **B-17, B-18**  
   Miniature IEC Star Delta  
     (WYE Delta) ..... **B-19**  
   Vacuum ..... **D-1 – D-9**  
   **XT** IEC ..... **B-34 – B-38, B-46**  
   Control Circuit Fuse Holder Kits ..... **A-40, A-92, B-223**  
   Control Modules, Advantage ..... **A-122, A-123**  
   Control Relays — *see* Relays  
   Coordination/Short Circuit Studies ..... **J-2**  
   Current Transformer Overload Relays ..... **B-95**  
   Current Transformers  
     D64 Type ..... **I-3**
- D**
- DC Coils for Contactors and Starters ..... **A-17, A-45, A-93, A-95, B-57, B-220, C-38, C-41, C-43, C-45, C-47**  
 DC Contactors — *see* Contactors  
 DC Relays — *see* Relays  
 Definite Purpose Contactors and Starters ..... **C-1 – C-48**  
 DeviceNet ..... **A-119**  
 DIN Rail Mounting ..... **A-17, A-41, A-121**  
   MMPs and CMCs ..... **B-124, B-151, B-197**
- E**
- Eaton's Training — *see* Education Programs  
 Education Programs  
   About Eaton's Training ..... **K-2**  
   Interactive Classrooms ..... **K-2**  
 EESS ..... **J-1 – J-6**  
 Electrically Held Lighting Contactors ..... **E-2 – E-7**  
 Electronic Overload Relays  
   Freedom ..... **A-66 – A-72**  
   **XT** IEC ..... **B-102 – B-108**  
 Engineering Services and Systems ..... **J-1 – J-6**
- F**
- Factory Modifications — *also see* Modifications  
 Field Engineering Services ..... **J-1 – J-6**  
 Fingerproof Shields ..... **A-41, B-23, B-56, B-95, B-123, B-223**  
 Fuse Blocks  
   Control Circuit, Panel Mounted ..... **B-223**  
   Starter/Contactor Mounted ..... **A-39, A-92, C-9**  
 Fuse Holder Kits, Control Circuit ..... **A-40, A-92, B-223**
- G**
- Ground Fault  
   Monitors ..... **I-9**  
   Relays ..... **I-2**
- H**
- Handle Mechanisms  
   Manual Motor Protectors ..... **B-120, B-121**  
 Harmonic Studies ..... **J-2**  
 Heater Coils, Overload Relays ..... **D-4**  
 Heater Packs, Overload Relays ..... **A-62 – A-65, A-106, A-107, B-216, B-217**  
 Heaters  
   A200 Starters ..... **A-106, A-107**  
   Freedom ..... **A-62 – A-65**  
   V200 Starters ..... **D-4**
- I**
- IEC  
   Accessories ..... **B-5 – B-9, B-21 – B-23, B-47 – B-56, B-194 – B-197, B-218 – B-224**  
   Combination Motor  
     Controllers ..... **B-145 – B-161**  
   Contactors ..... **B-34 – B-38, B-46, B-180 – B-182, B-207 – B-210**  
   Control Relays and Timers ..... **B-2 – B-14**  
   Manual Motor Protectors and  
     Controllers ..... **B-109 – B-144**  
   Mini Contactors ..... **B-17 – B-19**  
   Mini Control Relays ..... **B-4**  
   Mini Overload Relays ..... **B-20**  
   Starters ..... **B-39 – B-45, B-183 – B-189, B-212, B-213**  
   Timers ..... **B-8, B-9, B-53**  
 Industrial Control Transformers  
   CE Marked ..... **H-23 – H-30**  
   Machine Tool ..... **H-2 – H-22**  
     Type MTA ..... **H-2 – H-6**  
     Type MTC ..... **H-7, H-8**  
     Type MTE ..... **H-9 – H-17**  
     Type MTG ..... **H-9, H-14, H-17**  
     Type MTK ..... **H-18 – H-22**  
   Inside-the-Delta Soft Starters ..... **G-18, G-27 – G-30**  
   Interface Module, AC/DC ..... **A-42, B-224**  
   IQ Central Monitoring Unit ..... **A-132, A-133**

July 2008

**K**

## Kits

- Auxiliary Contact — *see* Auxiliary Contact Kits
- Contacts (Renewal Parts) . . . . . **A-17, A-48 – A-50, A-95, A-96, A-121, A-135 – A-138 B-57, B-198, B-225 – B-229**
- DC Coils . . . . . **A-17, A-45, A-46, A-93, A-95, B-57, B-220, C-38**
- DC/AC Interface Module . . . . . **A-42, B-224**
- Fuse Block . . . . . **A-39, A-92**
- Fuse Holder, Control Circuit . . . . . **A-40, A-92, B-223**
- Mechanical Interlock . . . . . **A-16, A-39, A-92, A-120, B-22, B-54, B-197, B-222, C-8, C-33, C-37, C-41, D-4**
- Reversing . . . . . **A-16, A-39, B-22, B-54, B-197**
- Transient Suppressor . . . . . **A-41, A-92, B-22, B-52, B-223**

**L**

- Land Transportation DC Contactors . . . . . **C-41 – C-48**
- Lighting Contactors
  - Electrically Held . . . . . **E-2 – E-7**
  - Magnetically Latched . . . . . **E-17 – E-19**
  - Mechanically Held . . . . . **E-8 – E-16**
- Line Side Adapters . . . . . **B-123**
- Load Flow Studies . . . . . **J-2**

**M**

## Magnet Coils

- DC for Contactors and Starters . . . . . **A-17, A-45, A-46, A-93, B-57, B-220, C-31, C-38, C-41**
- Renewal Parts . . . . . **A-45, A-48 – A-50, A-95 – A-98, A-121, A-135 – A-138, B-57, B-225 – B-229, C-34, C-38, C-39, C-41, D-5**
- Magnetic Shoe Brakes . . . . . **A-141 – A-144**
- Magnetically Latched Lighting Contactors . . . . . **E-17, E-18**
- Manual Motor Protectors and Controllers
  - XT** IEC MMPs . . . . . **B-109 – B-144**
- Manual Motor Switches . . . . . **F-2**
- Manual Starters
  - Single-Phase . . . . . **F-3 – F-8**
  - Three-Phase . . . . . **F-5 – F-8**
- Mechanical Interlock Kits . . . . . **A-16, A-39, A-92, A-120, B-22, B-54, B-197, B-222, C-33, C-37, C-41, D-4**
- Mechanically Held Lighting Contactors . . . . . **E-8 – E-16**

## Miniature Control, IEC

- XT** Contactors and Overload Relays . . . . . **B-15 – B-29**
- XT** Control Relays and Timers . . . . . **B-4, B-9**
- Motor Disconnect
  - Operator Mechanisms . . . . . **B-120, B-121**
- Motor Protection — *also see* Protective Relays
- Motor Rating Data . . . . . **A-147, A-148, C-32**
- Mounting Plates, Starter . . . . . **A-16, A-46, A-47, A-121, B-95, B-221**
- Multispeed Starters
  - Advantage . . . . . **A-112, A-113**
  - A200 . . . . . **A-83**

**N**

## NEMA

## Accessories

- Advantage . . . . . **A-119 – A-123, A-132 – A-134**
- A200 . . . . . **A-91 – A-93**
- Freedom . . . . . **A-39 – A-47**
- IT** . . . . . **A-13 – A-16**
- Vacuum . . . . . **D-4**

## Contactors

- Advantage . . . . . **A-109**
- A200 . . . . . **A-74 – A-76**
- Freedom . . . . . **A-27 – A-29**
- IT** . . . . . **A-4 – A-6**
- Vacuum . . . . . **D-1 – D-9**

## Starters, Full Voltage AC

- Advantage . . . . . **A-110 – A-113**
- A200 . . . . . **A-79 – A-83**
- Freedom . . . . . **A-30 – A-35**
- IT** . . . . . **A-7 – A-9**
- Vacuum . . . . . **D-1 – D-9**

**O**

## Operator Mechanisms

- Manual Motor Protector . . . . . **B-120, B-121**
- Overload Relays
  - Bimetallic . . . . . **A-60 – A-65, A-99 – A-107, B-93 – B-101 B-214 – B-217, C-18**
  - Current Transformer Operated . . . . . **B-95**
  - Electronic . . . . . **A-66 – A-72, B-102 – B-108, C-25**
  - Heater Coil Tables . . . . . **D-4**
  - Heater Packs . . . . . **A-60 – A-65, A-107, B-217, C-14**
  - Interchangeable Heater . . . . . **A-60 – A-65, A-99 – A-107, B-212 – B-217**
  - Mini Overload Relays . . . . . **B-20**
  - Modular **IT** Solid-State . . . . . **A-14**



July 2008

Solid-State, continued

- Contactors/Controllers ..... **G-11**
- Overload Relays..... **A-66 – A-72,**
- Starters, Reduced Voltage ..... **G-1 – G-53**
- Timers, Starter Mounted..... **B-222, C-8**

Star Delta (WYE Delta)

- Electronic Timers..... **B-9**
- Miniature Contactors..... **B-19**
- Starters..... **B-42 – B-45**

Starters

- Adapter Plates ..... **A-16, A-46, A-47,**  
**B-196, B-197, B-221**

Advantage

- Non-reversing ..... **A-109, A-111**
- Reversing ..... **A-109, A-111**
- Two-Speed ..... **A-112, A-113**

A200

- Non-reversing ..... **A-79 – A-82**
- Reversing ..... **A-79 – A-82**
- Two-Speed ..... **A-83**

Combination — see Combination Starters

Definite Purpose ..... **C-11 – C-25**

Freedom

- Interchangeable Heater IEC..... **B-212, B-213**
- NEMA ..... **A-30 – A-33**
- Single-Phase..... **A-34**

*IT*

- IEC..... **B-183 – B-189**
- NEMA ..... **A-7 – A-9**

Manual

- Fractional Horsepower ..... **F-4**
- Single-Phase..... **F-3 – F-8**
- Three-Phase ..... **F-5 – F-8**

Multispeed

- Advantage ..... **A-112, A-113**
- A200 ..... **A-83**
- Freedom — NEMA..... **A-33**
- XTIEC**..... **B-39 – B-45**
- XTIEC** Star Delta (WYE Delta) ..... **B-42 – B-45**

Surge Suppressor Kit ..... **A-41, A-92, B-22,**  
**B-52, B-223, E-2**

System Analysis, power Distribution ..... **J-2**

**T**

Thermal Overload Relays

- Heater Packs..... **A-65, A-106, A-107, B-215, B-217**
- Interchangeable Heater..... **A-60 – A-65,**  
**A-99 – A-107, B-214 – B-217**
- Miniature IEC ..... **B-20**
- XTIEC**..... **B-93 – B-101**

Timers

- Contactors and Starters..... **A-40, B-8, B-53,**  
**B-222, C-8, E-4, E-5**
- XTIEC** ..... **B-9**

Torque Limiters ..... **G-2, G-3**

Transformers

- Industrial Control ..... **H-2 – H-30**

Transient Suppressors ..... **A-41, A-92, B-22,**  
**B-52, B-223, E-2**

Two-Speed Starters

- Advantage..... **A-112, A-113**
- A200..... **A-83**
- Freedom — NEMA ..... **A-33**

**U**

Undervoltage Release Mechanism

- Manual Motor Protectors..... **B-120**

Utilization Categories ..... **A-145, A-146**

**V**

Vacuum

- Contactors..... **D-1 – D-9**
- Starters ..... **D-1 – D-9**

Vacuum Replacement Breakers ..... **J-3**

**W**

Westinghouse Product Support —

- EESS Services ..... **J-3**

WYE Delta

- Electronic Timers ..... **B-9**
- Miniature Contactors..... **B-19**
- Starters ..... **B-42 – B-45**

**X**

**XTIEC** Motor Control ..... **B-2 – B-177**

- Approvals for World Markets ..... **B-167 – B-169**
- Combination Motor Controllers ..... **B-145 – B-161**
- Contactors, Starters and  
Overload Relays..... **B-30 – B-108**
- Manual Motor Protectors..... **B-109 – B-144**
- Miniature Controls ..... **B-15 – B-29**
- Relays and Timers ..... **B-2 – B-14**
- Type 2 Coordination..... **B-162 – B-166**
- Utilization Categories..... **B-170, B-171**

